



FRL Series

Interchange with Hansen
2RL & 3RL Series

PLUGS

2FRL SERIES
3/8"

SOCKETS

AUTOMATIC

PLUGS

3FRL SERIES
1/2"

SOCKETS

AUTOMATIC

| | CAT. NO. | | HANSEN NO. | | CAT. NO. | | HANSEN NO. | | CAT. NO. | | HANSEN NO. | |
|--|----------|----------|------------|----------|----------|-------|------------|----------|----------|--|------------|--|
| FEMALE THREAD | | | | | | | | | | | | |
| 1/4 FPT | 2L41 | 2-L16 | 2R4004 | 2-R16 | 3L51 | 3-L16 | 3R4015 | 3-R16 | | | | |
| 3/8 FPT | 2L43 | 2-L21 | 2R4204 | 2-R21 | | | 3R5005 | 3-R21 | | | | |
| 1/2 FPT | 2L45 | 2-L26 | 2R4404 | 2-R26 | 3L55 | 3-L26 | 3R5205 | 3-R26 | | | | |
| 3/4 FPT | | | | | | | 3R5405 | 3-R31 | | | | |
| MALE THREAD | | | | | | | | | | | | |
| 1/8 MPT | 2L38 | 2-L10 | 2R4104 | 2-R15 | 3L50 | 3-L15 | 3R4905 | 3-R15 | | | | |
| 1/4 MPT | 2L40 | 2-L15 | 2R4304 | 2-R20 | 3L52 | 3-L20 | 3R5105 | 3-R20 | | | | |
| 3/8 MPT | 2L42 | 2-L20 | 2R4504 | 2-R25 | 3L54 | 3-L25 | 3R5305 | 3-R25 | | | | |
| 1/2 MPT | 2L44 | 2-L25 | | | 3L56 | 3-L30 | 3R5505 | 3-R30 | | | | |
| 3/4 MPT | | | | | | | | | | | | |
| HOSE STEM (Require Hose Clamps) | | | | | | | | | | | | |
| 1/4 I.D. | 2L46 | 2-L17 | 2R4604 | 2-R17 | 3L58 | 3-L17 | 3R5605 | 3-R17 | | | | |
| 5/16 I.D. | | | 2R4704 | 2-R195 | | | | | | | | |
| 3/8 I.D. | 2L48 | 2-L22 | 2R4804 | 2-R22 | 3L59 | 3-L22 | 3R5705 | 3-R22 | | | | |
| 1/2 I.D. | 2L49 | 2-L27 | 2R4904 | 2-R27 | 3L60 | 3-L27 | 3R5805 | 3-R27 | | | | |
| 3/4 I.D. | | | | | 3L61 | 3-L32 | 3R5905 | 3-R32 | | | | |
| PUSH-ON HOSE STEM | | | | | | | | | | | | |
| 3/8 I.D. | | | 2R1714 | | | | 3R1815 | | | | | |
| 1/2 I.D. | | | 2R1814 | | | | | | | | | |
| SELF-STORING AIR HOSE | | | | | | | | | | | | |
| 3/8 I.D. | | | 2R1704 | | | | 3R1805 | | | | | |
| 1/2 I.D. | | | | | | | | | | | | |
| REUSABLE HOSE CLAMP | | | | | | | | | | | | |
| ID OD | | | | | | | | | | | | |
| 1/4 X 1/2 | 2LPB3 | 2-L18B3 | 2RSB3 | 2-R18B3 | | | 3RSD7 | 3-R23D7 | | | | |
| 1/4 X 9/16 | 2LPB5 | 2-L18B5 | 2RSB5 | 2-R18B5 | | | 3RSD9 | 3-R23D9 | | | | |
| 1/4 X 5/8 | 2LPB7 | 2-L18B7 | 2RSB7 | 2-R18B7 | | | 3RSD11 | 3-R23D11 | | | | |
| 1/4 X 11/16 | 2LPB9 | 2-L18B9 | 2RSB9 | 2-R18B9 | | | 3RSD13 | 3-R23D13 | | | | |
| 3/8 X 5/8 | 2LPD7 | 2-L23D7 | 2RSD7 | 2-R23D7 | | | 3RSP13 | 3-R28P13 | | | | |
| 3/8 X 11/16 | 2LPD9 | 2-L23D9 | 2RSD9 | 2-R23D9 | | | 3RSP15 | 3-R28P15 | | | | |
| 3/8 X 3/4 | 2LPD11 | 2-L23D11 | 2RSD11 | 2-R23D11 | | | 3RSP17 | 3-R28P17 | | | | |
| 3/8 X 13/16 | 2LPD13 | 2-L23D13 | 2RSD13 | 2-R23D13 | | | 3RSP19 | 3-R28P19 | | | | |
| 1/2 X 13/16 | 2LPP13 | 2-L28P13 | | | | | | | | | | |
| 1/2 X 7/8 | 2LPP15 | 2-L28P15 | | | | | | | | | | |
| 1/2 X 15/16 | 2LPP17 | 2-L28P17 | | | | | | | | | | |
| 1/2 X 1 | 2LPP19 | 2-L28P19 | | | | | | | | | | |

BALL CHECK Ball check plugs eliminate hose whip at disconnect by checking the rapid flow of downstream exhaust air.

| | | | | | |
|---------------|--|--|-------|--------|--|
| 1/2 I.D. HOSE | | | 3L60G | 3-L27G | |
| 3/4 I.D. HOSE | | | 3L61G | 3-L32G | |

FRL 3/8" PLUG
ACTUAL SIZE

FRL 1/2" PLUG
ACTUAL SIZE